


Analog Ammeter




Analog Voltmeter

## Experiment no. 1

- **Objective :** Introduction to various Supply System, ammeter, Voltmeter, wattmeter, Tachometer, Reostat, Transformer.
- **Apparatus required :** Demonstration of various instruments like ammeter, voltmeter, wattmeter, energy meter, Tachometer, Reostat, various capacitors, various resistors, AC & DC Power Supply.
- **Theory of Experiments:** Ammeter is employed for measuring of current in a circuit & connected in Series. The voltage drop across ammeter terminal is very low. This requires that the resistance of the ammeter should be as low as possible. The current carrying capacity whereas the current to be measured may be quite high. So for protecting the equipment a low resistance is connected in parallel to the current

Teacher's Signature: \_\_\_\_\_

- WRITELINE -



Rheostates


coil & it is known as Shunt.

- Voltmeter:

Voltmeter is employed to measure the potential difference across any two points of a circuit. It is connected in parallel across any element in the circuit. The resistance of voltmeter is kept very high. By connecting a high resistance in series of the voltmeter with the current coil of the instruments. The actual voltage drop across the current coil of the voltmeter is only a fraction of total voltage applied across the voltmeter which is to be measured.

- Tachometer: Tachometer is an instrument to measure the speed in (revolutions per minute) rpm. The speed of a rotating shaft is measured by inserting a tapered hole in the rotating shaft and projecting part of the tachometer into the tapered hole.

Teacher's Signature: \_\_\_\_\_



Multimeter

Speed of which is to be measured.

#### o Rheostat :

Rheostat are made up of high resistivity material, like nickel, chromium iron alloy closely wound over a circular tube. These are available both in single tube & double tube. inter turn insulation is provided to avoid short circuiting of turns. the tube of rheostat is made of insulating material, like asbestos. These are employed at places where resistance of a circuit is to be varied without breaking the circuit.

#### o Various ~~Supply System~~ :

##### a) AC Supply System -

These are two types of supply wire line In case the fourth wire is there it is natural while voltage b/w two phases lines is 400v, b/w any phase line & neutral if it is 230v.

Teacher's Signature: \_\_\_\_\_

WRITO-LINE \_\_\_\_\_

### b) DC Supply System:

There are two types of DC Supply System.





- (i) From Battery: we use rectifiers for 6v or 12v DC Supply current.
- (ii) From generator.

### o Multimeter:

Multimeter is measuring instrument used to measure The current, voltage & resistance. These can be used to troubleshoot many electrical equipments such as domestic appliances power supplies etc.

~~11.8  
2.191-21~~

Teacher's Signature: \_\_\_\_\_



## Experiment no. 2

- Aim:- Study of CRO & Frequency Generator.


- Theory:-

An outline explanation of how an oscilloscope works can be given using the block diagram shown.

Like a television screen, the screen of an oscilloscope consist of a cathode Ray tube. Although the size & shape are different, the operating principle is the same. Inside the tube is a vacuum. The electron beam emitted by the heated cathode at the rear end is accelerated and focused by anodes, & strikes the front of the tube, producing a bright spot on the phosphorescent screen.

The electron beam is bent, or



Teacher's Signature: \_\_\_\_\_




deflected, by voltages applied to two sets of plates fixed in the tube. The horizontal deflection plates or X-Plates produce side to side movement. As you can see, they are linked to a system block called the time base. This produces a saw tooth waveform. During the rise phase of the saw tooth, the spot is driven at a uniform rate from left to right across the front of the screen. During the falling phase, the electron beam return rapidly from right to left, but the spot is blanked out so that nothing appears on the screen. In this way, the time base generates the X-axis of the V/t graph.

The slope of rising phase varies with the frequency of the saw tooth & can be adjusted, using the time / DIV control, to change the scale of the X-axis. Dividing the oscilloscope screen into squares

Teacher's Signature: \_\_\_\_\_



Y-Pos



~~INVERT~~






allows the horizontal scale of the  $x$  axis. Dividing Expressed in seconds, milliseconds or microseconds per division ( $s/div$ ,  $ms/div$ ,  $\mu s/div$ ). Alternatively, if the squares are 1 cm apart, the scale may be given as  $s/cm$ ,  $ms/cm$ ,  $\mu s/cm$

The signal to be displayed is connected to the input. The AC/DC switch is usually kept in the DC position (switch closed) so that there is a direct connection to the  $y$ -amplifier. In AC position (switch open) a capacitor is placed in the single path. The ~~capacitor~~ blocks DC signals but allows AC signals to pass.

The  $y$ -amplifier is linked in turn to a pair of  $y$ -plates so that the resulting display is neither too small nor too large, but fits the screen & can be seen clearly. The vertical scale is usually given in  $V/DIV$  or  $m$   $V/DIV$ .

Teacher's Signature: \_\_\_\_\_



DC

AC

GND

Voltage division, -Channels, AC, DC &  
GND Knobs

The trigger circuit is used to delay the time base waveform so that the same section of the input signal is displayed on the screen each time the spot moves across. The effect of this is to give a stable picture on the oscilloscope screen, making it easier to measure & interpret the signal.

Changing the scales of the X-axis & Y axis allows many different signals to be displayed. Sometimes, it is also useful to be able to change the positions of the axes. This is possible by using the X-Pos & Y-Pos controls. For example, with no signal applied, the normal trace is a straight line across the center of the screen. Adjusting Y-Pos allows the zero level on the Y-axis to be changed moving the whole trace up or down on the screen to give an effective display of signals like pulse waveforms.

Teacher's Signature: \_\_\_\_\_

which do not alternate b/w positive & negative values.

- on/off switch :- Pushed into switch the oscilloscope on the green LED illuminates.

# X-Y control :- Normally in the out positions.

When the X-Y button is pressed IN, the oscilloscope does not display a V/T graph instead, the vertical axis is controlled by the input signal to CH II. This allows the oscilloscope to be used to display a V/V voltage/voltage graph.

The X-Y control is used when you want to display component characteristic curves, or Lissajous figures.

# TV-separation : oscilloscopes are often used to investigate wave form inside

Teacher's Signature: \_\_\_\_\_

television system. This control allows the display to be synchronized with the television system but so that the signals from different points can be compared.

# Time / Div: Allows the horizontal scale of the V/t graph to be changed.

With more experience of using the oscilloscope, you will develop a clear understanding of the functions of the important trigger controls & be able to use them effectively.

• Intensity & Focus :- Adjusting the intensity control changes the brightness of the oscilloscope display. The focus should be set to produce a bright clear trace.

If required, TR can be adjusted using a small screwdriver so that the oscilloscope trace is exactly horizontal when no signal is connected.

Teacher's Signature: \_\_\_\_\_

WRITELINE \_\_\_\_\_

- X - Pos : Allows the whole V/t graph to be moved from side to side on oscilloscope screen.

This is useful when you want to use the grid in front of the screen to make measurements, for example, to measure the period of a waveform.

- X-Pos I and Y-Pos II : These controls allow the corresponding trace to be moved up or down, changing the position representation O v on the oscilloscope screen.

To investigate an alternating signal, you adjust Y-Pos so that the Ov level is close to the centre of the screen. For a pulse waveform, it is more useful to have O-v close to the bottom of the screen. X-Pos I & Y-Pos II allows the Ov levels of the two traces to be adjusted independently.

- INVEST: When the invert button is

Teacher's Signature: \_\_\_\_\_

is pressed IN, the corresponding signal is turned upside down, or inverted, on the oscilloscope screen. This feature is sometimes useful when comparing signals.

- CH I & CH II inputs: Signals are connected to the BNC input sockets using BNC Plugs.

The smaller sockets next to the BNC input socket provides an additional OV, Ground or Earth connection.

- Volts / Div: Adjust the vertical scale of the V/t graph. The vertical scales for CH I & CH II can be adjusted independently.

- DC / AC / GND Switches: In ~~the~~ The DC positions, the signal input is connected directly to the Y-amplifiers of the corresponding channel, CH I or CH II. In the AC position, a capacitor is connected into the signal path so that DC voltages are blocked & only changing AC

Teacher's Signature: \_\_\_\_\_

Signals are displayed.

in the GND position, the input of the Y-amplifier is connected to 0V. This allows you to check the position of DV on the oscilloscope screen. The dc position of these switches is correct for most signals.

### • Trace Selection Switches :

The settings of these switches control which traces appear on the oscilloscope screen -

~~WZ Tapes~~

Teacher's Signature: \_\_\_\_\_

WRITO-LINE \_\_\_\_\_

- Aim : measure the frequency , voltage, current with help of CRO .
- Study Analog / Digital multi-meters & Function / Signal generator:-
- Theory :-

Cathode Ray oscilloscope :- The cathode Ray oscilloscope is probably the most versatile tool for the development of electronic circuits & Systems, & has been one of the most important tools in the development of modern electronics. The cathode ray oscilloscope is device that allows the amplitude of electrical signals, whether they be voltage, current, power etc. to be displayed primarily as function of time. The oscilloscope depends on the movement of an electron beam, which is then made visible, allowing the beam to impinge on a phosphor surface, which produces a visible spot. If the electron beam is deflected in either of two orthogonal axes, such as families X & Y-axes.

Teacher's Signature: \_\_\_\_\_

used in conventional graph construction, The luminous spot can be used to create two dimensional displays. Typically, the  $X$  axis of oscilloscope is deflected at constant rate, relative to time, & the vertical or  $Y$ -axis is deflected in response to an inputs stimulus such as a voltage. This produces the time dependent variation of input voltage which is very important to design development of electronic circuits.

### $\Rightarrow$ Cathode Ray tube :-

A heated emits electrons which accelerated to the first accelerating anode, or pass a accelerating anode, through a small hole in the control grid.

The amount of cathode current, which governs intensity of spot,

can be positive than the cathode

so that electron beam will be

accelerated in the electric field

A focusing anode is mounted just ahead of the preaccelerating anode and a cylinder. Following the focusing anode is the accelerating

Teacher's Signature: \_\_\_\_\_

WRITO-LINE \_\_\_\_\_

anodes which gives the electron beam its last addition of energy before its journey to phosphor screen.


### - Function Generator A Function

A function generator is a versatile instrument which produces different waveforms of adjustable frequency over a wide range. The common output waveforms are the sine, square, triangle and saw tooth waves. Frequency of these wave forms may be adjusted from a fraction of Hertz to several KHz. The various output of generator can be made available at some time, for example generator can provide a square wave to test the linearity of amplifier and simultaneously provide a saw tooth to drive horizontal deflection amplifier of CRO to provide duplex

Teacher's Signature: \_\_\_\_\_

WRITO-LINE \_\_\_\_\_

## Modal waveforms



Sinesoidal waveform

## • Observation :-

S.No.	No. of vertical divisions (X)	Voltage/Division (Y)	$V_p - P_c$	$V_m = V_p - P/2$
1.	8	20 mV	16 mV	80 mV
2.	10	20 mV	20 mV	100 mV
3.	8	20 mV	16 mV	80 mV

## B: Measurement of frequency

## Procedure:

1. Make the connection as per the diagram shown above.
2. Put the CRO on a single channel mode & bring the CRO into operation by adjusting the trace of the beam to a normal brightness & into a thin line.
3. Now apply the Sine Sodial wave form of different frequencies by using the level

Teacher's Signature: \_\_\_\_\_


WRITO-LINE \_\_\_\_\_

& COARSE buttons of the function generator.

4. Note down the Horizontal scale Period ( $T$ ) in second by observing difference between the two successive Peaks of the waveform.

$\Rightarrow$  Observation :-

S.No.	No. of Horizontal Division ( $X$ )	Time / Division ( $Y$ )	$T = X \cdot Y$	$F = 1/T$
1.	19 ms	2 ms	38 ms	26.3 Hz
2.	22 ms	2 ms	44 ms	22.7 Hz
3.	19 ms	2 ms	38 ms	26.3 Hz



Teacher's Signature: \_\_\_\_\_

WRITO-LINE \_\_\_\_\_

Aim: Assemble house wiring including earthing for 1 Phase energy meter, mcb, ceiling Fan, tubelight, three pin socket & a lamp operated from two diff. positions. Basic functional study of components used in house wiring.

Apparatus required:

S.No.	Name of equipment	Range	QTY.
1.	Tubelight	1-Φ, 230V, 50Hz, 40watt	01
2.	ceiling Fan	1-Φ, 230V, 50Hz, 80watt	01
3.	One way Switch	1-Φ, 230V, 50Hz	03
4.	mCB	230V, 50Hz, 10Amp	02
5.	Two way Switch	1-Φ, 230V, 50Hz	02
6.	wire (P.V.C)	40 BSWG, 0.121 mm² mm²	
7.	Three pin socket	1-Φ, 230V, 50Hz, 5A	01

Teacher's Signature: \_\_\_\_\_


### Theory :

(a) House wiring : In this circuit three switch, one tubelight, one three pin socket, & one fan along with fan regulator are required. The circuit diagram for this wiring is shown in the figure where the neutral is connected to one terminal of the tube light switch  $S_1$ , Three pin socket switch  $S_2$  & Fan switch  $S_3$ .


Phase point of the supply is connected to the each other terminal of the tube light, three pin socket & fan. The other terminals of tubelight & three pin socket are connected to switch  $S_1$  &  $S_2$  & the other terminal of fan  $F_1$  is connected to switch  $S_3$  through fan regulator R.

(b) Stair case wiring ~~circuit~~ circuit : Stair case wiring or lamp circuit controlled by two switches. For the lamp to be controlled by two switches it is necessary to use two way switch. The wiring diagram is shown in ST & ST<sub>2</sub> are two way switches. The wiring diagram is shown

Teacher's Signature: \_\_\_\_\_



House wiring CKT Diagram



Staircase wiring CKT System

Expt. No.

L i  
to  
to  
The  
cor  
of

The  
tr  
ST  
of  
sup  
co  
lan  
Sim  
bl  
Ph  
a

• P  
(i) T  
m  
j  
(ii)  
(iii)

$L$  is lamp,  $c_1$  of  $ST_1$  is connected to phase  $P$  &  $c_2$  of  $ST_2$  is connected to one of the terminals of lamp  $L$ . The other terminal is connected in series to neutral  $N$ . terminals  $p_1$  of  $ST_1$  &  $ST_2$  are connected as shown.

The lamp can be controlled from both the position of the switches  $ST_1$  &  $ST_2$  e.g.: if  $c_1 p_1$  of  $ST_1$  are in contact &  $c_2 p_2$  of  $ST_2$  are also in contact, then bulb get supply & it glows. Now if any of the combination of  $ST_1$  or  $ST_2$  are disturbed lamp will switch off.


~~Similarly when  $c_1 p_2$  are in contact then bulb can glow if  $c_2 p_1$  are also connected. Any of the combination is it disturbed, bulb again switches off.~~

- Precautions:-
- (i) The Phase & neutral of the circuit should not directly come in contact it will result in to short circuit.
- (ii) Connection should be tight & insulated.
- (iii) Terminals of regulator should be properly connected to avoid any hazard.

Teacher's Signature: \_\_\_\_\_

WRITO-LINE

Earthing



Electric Bell



ceiling Rose




- o main components used in House wiring:
1. Switch: A Switch is used to make or break an electric circuit. The switch ~~so~~ should break the current without formation of an arc b/w the switchblades & contact terminals. A Switch must have a strong base & high insulation resistance.
  2. Wall sockets: They are used to contact the appliances with the electric supply. They are two types: (1) 2 Pin Sockets ~~(2)~~ 3-Pin Sockets. They are both 5 Amp and 15 amp current rating with 230 volt working voltage are used.
  3. Plugs: For taking power from socket outlets 2 pin or 3 pin plugs with 5 Amp or 15 Amp current rating 230 V working voltages are used.
  4. One way switch: Switch, which is used for ~~break~~ to make or break of light load circuit or controlling one point by one switch.

Teacher's Signature: \_\_\_\_\_

Switch



Socket outlet  
(S. A)



Two pin plug




Three pin plug




Two way switch




Push button switch



Fan regulator



Fuse



Fan



5. two way Switches : Switch , which is used ~~as~~ <sup>as</sup> ~~breaker~~ For Stair case wiring For controlling one point by two switches .

6. Push Button Switches : It consist of one blade , which is given a rocking motion by a push button . Its movement are normally used to control lighting circuit or bell switch .

7. Fan Regulator : It is normally used to control the speed of electric fan . we can say this as a selector switch .

8. Fuse : A fuse is a short piece of metal inserted in series with the circuit . which melt when excessive current flows through it and thus break the circuit . the material used for fuse element should pass the following properties

- (i) Low melting point .
- (ii) High conductivity or low resistivity .
- (iii) Free from oxidation .

Teacher's Signature: \_\_\_\_\_

9. Fan: Fan is a device, which circulates air surrounding the medium. It is simply a permanent single phase induction motor. Capacitor is permanently connected in series with stator windings.

10. Earthing: the process of connecting metallic bodies of all the electrical apparatus and equipment to the huge mass of earth by a wire having negligible resistance when a body is earthed, it is basically connected to the huge mass of earth wire having negligible resistance. Thus, the body is earthed, it is basically connected to the huge mass of earth wire having negligible resistance. Thus, the body attains zero potential of earth. thus ensures that whenever a live conductor comes in contact with the other body, the charged is neutralized to the earth immediately.

11. Electric Bell: A bell activated by the magnetic effect of an electric current.

12. ceiling Rose: it is basically used to control a single light fitting.

Teacher's Signature: *(Signature)*